



Important notes:

- * Up to two spacers can be used to load smaller reloads in a motor casing that is one or two sizes larger than the reload.
- * The additional weight per case spacer + extra casing length = 27 grams (54 grams when using 2 spacers)
- * The spacers can be used for all Pro29 casings. An XL spacer is not required. A regular spacer reduces an 6GXL case to a 6G case.

Instructions:

- (1) Drop spacer(s) into motor case with the rounded end towards the rounded end of the motor.
- (2) Install the reload kit as per instructions.
- (3) Verify that the space above the reload kit forward closure is completely occupied by the spacer(s).

REV	DESCRIPTION	DRAWN	CHKD	DATE
REVISIONS All changes must be processed and reprinted. Destroy all previous copies.				



CESARONI TECHNOLOGY INCORPORATED
 2561 STOUFFVILLE ROAD GORMLEY ONTARIO CANADA

Unless Otherwise Specified
 X/X ± 1/64
 .XX ± 0.010
 .XXX ± 0.002
 .XXXX ± 0.0005
 X° ± 0°-30°
 BREAK ALL SHARP EDGES .01 X 45°
 CHAMFER ALL TAPPED HOLES 90° TO THREADED DIAMETER

THIS DOCUMENT CONTAINS CONFIDENTIAL PROPRIETARY INFORMATION. UNAUTHORIZED USE OR REPRODUCTION IS PROHIBITED.

SCALE: 1:1	DATE (DD/MM/YY): 11/01/10
DRAWN BY: A.L.T.	DRAWING SIZE: A
WEIGHT: -	CUSTOMER: -
MATERIAL: Various	SURFACE TREATMENT: -

FILE NAME: Pro29-Case_Spacer1.dwg
TITLE: Pro29 Case Spacer in 2G and 3G Case with 1G Reload
SHEET: 1 OF 1
PROJECT #: 0