Aerograph instruction booklet

SPECIFICATIONS HS-200 Nozzle diameter: 0.2mm-0.3mm 2cc Fluid Cup capatity:

APPLICATIONS

Commercial arts, illustrations, photo retouching, hobby and crafts.


■ HOW TO SPRAY


- 1. Fill fluid in the cup after thinning appropriately.
- 2. Hold the airbrush lightly in your hand.
- 3.By pressing the main lever, a stream of air emerges. Then draw it backward gradually for Color atomization.
- 4. The spray pattern is in accordance with the distance between a work surface and a air brush.
- 5. For fine line spray, remove the needle cover and hold the air brush near a work surface.

MAINTENANCE

- 1. Empty the fluid cup and wash with water or solvent by a brush.
- 2. Refill cup with water or solvent, then block the needle cover with a finger and spray. The air flows backward into nozzle to clean the paints remained the air brush.

AIRBRUSH MECHANISM





Parts Name

- 1. Needle CaP
- 2. Nezzle Cap
- 3. Nozzle
- O-Ring for Nozzle Cap
- Needle
- O-Ring for Needle Guide
- Needle Guide
- 8. Lid for Color Cup
- Operation Lever
- 10. Lever Guide
- 11. Stopper
- 12. Needle Chucking Guide
- 13. Spring
- 14. Spring Case
- 15. Needle Chucking Net
- 16. Standard-Handle Adjusting
- 17. Adjustin Screw
- 18. Guide Screw
- 19. Lever Guide O-Ring
- 20. Valve O-Ring
- 21. Valve Body
- 22. Valve Rod O-Ring
- 23. Valve Rod
- 24. Valve Spring
- 25. Valve Screw
- 26. Hose Connector Nut
- 27. O-Ring for Hose Connector
- 28. Hose Connector
- 29. Nozzle Spanner
- 30. Allen Screw O -Ring
- 31. Allen Screw
- 32. Adjusting Screw O-Ring
- 33. Adjusting Screw